Aspen C90 - "Aspen Fun"
Inventory

Welcome Aboard the Aspen Fun. The C90 Cruiser is known for its innovative power proa hull design which gives you unheard of fuel economy. Using 4-5 gallons per hour at cruising speeds of 18-21 kts.

ANCHORING: The main anchor is on the bow roller, the extra is in the port aft cockpit storage area. Note: if the winch runs but the line/chain is not coming in the clutch is most likely not snugged up, using the wrench (Lewmar) from the blue owners info bag insert it in the top of the winch and tighten clockwise- test again be careful not to tighten to far as the bow roller can be bent with the motors force.

BARBEQUE: The barbeque is stored in the tip out aft cockpit wall bin along with the propane.

BATTERIES: The batteries are located in the starboard aft cockpit storage compartment. The house batteries are the two forward, the single to the aft is the start.

BERTHS: There is a king berth forward and the dinette folds down for a queen size berth. There is a ¼ berth in the starboard hull which can also be used for storage.

BILGE PUMPS: There are 3 bilge pumps per hull each in water tight compartments and a emergency large capacity pump located under the engine. All bilge pumps are on automatic float switches and powered by full time power even if the switches are off.

DINGHY: Always wear your life jacket when using the dinghy. The 8'9" foot dinghy has a 450 lb. capacity and allows 3 people on board safely.

ELECTRONICS: The Aspen Fun is equipped with a Garmin 4210 10" color chart plotter/sounder and an Icom VHF marine radio.

ENGINE: The engine is located in the starboard hull mid ships. It can accessed under the dinette or thru the starboard lazarette.

FUEL TANKS: There are 2 fuel tanks on the Aspen Fun. Only diesel fuel. The tanks each have the capacity of 40 gallons for a total of 80 gallons.

GALLEY: The Aspen Fun galley is fully equipped with dishes, cooking pots and pans, silverware, glasses. You will need to bring seasonings, foil & plastic wrap, garbage bags, dish soap. *Linens and towels are provided for charters by San Juan Sailing and must be ordered one week in advanc*e.

HOLDING TANK: They holding tank is 28 gallons. To empty be away from shore and hold macerator switch on to dump. It's best to do when engine is off so you can hear

the change in motor speed when the tank is dry. There is also a pump out fitting on the step through at the transom gate.

HEATER: Wallace 30D runs off port fuel tank when it's more than 1/3 full

HOT WATER: There is a 6 gallon hot water tank 110V and tied to engine water jacket.

NAVIGATION: Charts are kept in the glove box and on the chart table to right of co-pilot.

SAFETY EQUIPMENT: Aspen Fun has 8 life jackets, two under the helm seat suspender inflating type, 6 in the starboard aft cockpit storage compartment in a blue tub. The flair kit and first aid kit are also stored under the helm seat. Fire extinguishers are located to port side of helm and on the aft wall of the ¼ berth.

OTHER: There are 2 deck chairs stored in the starboard lazarette.

SHORE POWER: 30 amp service cord is stored in tip out bin aft cockpit wall.

STOVE: The stove is propane and has a 15 lb. propane tank. Remember to turn on the tank on at the bottle and on with the control unit to the right of the stove. Turn switch at stove off after use and close bottle if leaving the boat for an extended period.

WATER: The boat has 2 water tanks, one in each hull to activate the port tank switch the water pump switch at the dash to port side. To activate starboard tank move switch to starboard. If switch is centered both pumps are off. Capacity is 50 gallons. Remember to not run water continuously to conserve your water supply.

TOOLS & SPARE PARTS: These items are located in the plastic bins in the port cockpit storage area and in the port cockpit aft wall storage area. Aspen Fun carries a bag with small tools, spare parts, wire connectors, and a wide assortment of other items that maybe needed.